How to reset heaphone/audio jack settings on Dell laptops

Click the Windows icon in the lower left corner to bring up programs list and click on Max Audio Pro.

	0	Groove Music					
	J L M	Java		C Microsoft Edge	Google Chrome	Internet Explorer	
		Mail					
	0	Maps		MS Education Store			
		MaxxAudioPro					
		Messaging					
	e	Microsoft Edge		—			
		Microsoft Endpoint Manager		File Explorer			
8		Microsoft Office Tools					
51		Microsoft Silverlight					
ų,		Microsoft Solitaire Collection					
Ģ		Microsoft Store					
ø	τĵ	Microsoft Teams					
	Ô	Mixed Reality Portal					
0	-6	Mobile Plans					
	þ	🌀 Mail - Shawn Wilts	9	6			
	/						

Click on Playback



At the bottom click on Advanced





Check "Show pop-up dialog when device is connected"

- reinsert the headphones into the jack and the pop-up dialog will open up
- select Headphones
- check "Don't show this dialog again" to stop the pop-up from coming up every time they plug in their headphones

Which device did yo	ou plug in?			
Mic in				
Line in				
Headphones / Hea	idset On-ear -			
External Speakers	External Speakers	s Medium 🔫		
Don't show this dialog again				
	ОК			